

# METHOD STATEMENT OF DRY WALL PARTITION

*Go along with these steps for efficient drywall partition.*

---

## Step 1:

Decide which sort of plasterboard you require.

## Step 2:

Draw a line on the floor or at the location where the wall will be placed.

## Step 3:

Cut and assemble wood for frame, using a screwdriver. A permanent adhesive may be used, but if you want to be able to clean the dry wall afterwards, it is not advised.

## Step 4:

Measure the plasterboard then cut it.

## Step 5:

Screw the frame onto the plasterboard.

## Step 6:

If you like, apply the insulation to your wall. Only cut it to the correct size and put it within your picture. Be sure you have the right type of insulation, depending on what you need: heat or noise, or both.

## Step 7:

Plaster or just cover the wall with some paper



PICK the  
BRICK  
EASY OFFICE FIT OUTS