



METHOD STATEMENT OF GYPSUM FALSE CEILING

A correct installation step for aesthetic false ceiling is the key.

Step 1: Taking Measurements

To start with, use your tape measure to measure the ceiling using a wall that is perpendicular to the joists. When you've done this, count from the centre of the joist that's 8 feet out from the wall. This is going to show you the starting point for laying your gypsum ceiling sheets.

Step 2: Create your own boards

Take your sharp knife and cut a piece of gypsum board to this exact duration. Using the T-square when defining the length of the gypsum board to ensure that the cut is fully straight. First, set up the two stepladders such that there is one on the wall from which you weighed the joist-and one in the centre of the space where the other end of the gypsum board lies. Place the board until the end of the cut is facing the wall. This way you can achieve flush gypsum board connexions in the centre of the ceiling of the building. Your assistant is expected to help keep the gypsum board against the ceiling.

Step 3: Screwing

Take your screw gun and fasten drywall screws every six inches through the sides of the frame, make sure that you only do this when beneath a joist or it doesn't stay properly. If the roof is built with this degree of carelessness, the space would be incredibly dangerous so make sure you prepare accordingly. The location of the joist would not be difficult to judge as you can trace their length from behind either side of the gypsum frame. You would be able to repair screws parallel to current ones while connecting later boards to ensure you screw through the joists correctly. Lay them down to the end in a tidy, competent way. Ensure that the screw heads push under the gypsum board's surface.

Step 4: Seams Simple

Next, smother the drywall tape between the seams of the gypsum sheets. Then use your drywall knife to distribute with joining compound. Free use of joining compound to fill sunken holes in the screw. For this process, the drying period is about four hours. Use your drywall sandpaper to smooth the dry joining compound over. Before adding an incredibly thin third layer, a second layer of compound must then be applied, using the same procedure. You should then start painting your new gypsum board ceiling after this has been dried and sanded.



PICK the
BRICK

EASY OFFICE FIT OUTS